

LOFPLEAT™ HP high performance filter cartridges

Eaton's LOFPLEAT HP filter cartridges are suitable for a wide range of process applications including aqueous solutions, chemicals, process water, RO prefilters and ink.

This high efficiency, high performance filter cartridges are constructed with a large surface area, melt blown polypropylene filter material for high dirt-holding capacity with low initial pressure drop.

Features and benefits

- Fits broad range of applications with 0.2 to 20 micron retention ratings
- Beta rating of 5000, 99.98% efficiency
- High-flow and long service life for minimum maintenance
- Fixed pore structure prevents dirt unloading even at high differential pressure
- Heavy-duty molded cage for high structural strength

Design

Filter material Polypropylene

Inner core, cage, end caps

Polypropylene

Gaskets/O-rings Silicone (standard), Buna-N, EPDM, FPM, FEP encapsulated (O-rings only)

Retention ratings 0.2, 0.45, 1, 2.5, 5, 10, 20 μm @ 99.98% efficiency

Technical data

Nominal lengths 5", 9.75", 10", 20", 30", 40" (12.7, 24.7, 25.4, 50.8, 76.2, 101.6 cm)

Outside diameter 2.7" (6.9 cm)

Inside diameter 1" (2.54 cm)

Surface area 0.65 m² per 10" element

Max. operating temperature 80°C


Max. differential pressures 5.2 bar @ 21 °C 2.8 bar @ 80 °C

Recommended differential change-out pressure for disposal 2.4 bar




LOFPLEAT HP high performance filter cartridges

Flow rate* (21 °C per 10" filter cartridge)



^{*} For liquids other than water, multiply pressure drop by fluid viscosity in centipoise.

Ordering code



-20:

Efficiency of retention

Beta ratio retention of efficiency	Beta 5000 99.98%	Beta 100 99%	Beta 50 98%
0.2 μm	0.2	0.1	0.05
0.45 μm	0.45	0.3	0.2
1 μm	1	0.6	0.3
2.5 µm	2.5	2	1.5
5 μm	5	4	3
10 µm	10	8	7
20 µm	20	17	15

Beta ratio =

Upstream particle counts

Downstream particle counts

The micron ratings shown at various efficiency and beta ratio value levels were determined through laboratory testing, and can be used as a guide for selecting cartridges and estimating their performance. Under actual field conditions, results may vary somewhat from the values shown due to the variability of filtration parameters. Testing was conducted using the single-pass test method, water at 9.46 //min/10° cartridge. Contaminants included latex beads, coarse and fine test dust. Removal efficiencies were determined using dual laser source particle counters.



LOFPLEAT HP filter cartridges are available with a variety of gasket, O-ring and end cap configurations.

> EN EF-LPHP 10-2016

Contact your **authorized Eaton distributor** today: **Commercial Industrial Supply**

Single open end, internal O-ring

222/Fin single open end, triple bayonet

1444 East Main Street Rock Hill, SC 29730 USA Tel: (866) 777-8001 Email: info@emailcis.com

i**pply** h © 2016 Eaton. All rights reserved. All trademarks and registered trademarks are the property of their respective owners. All information and recommendations appearing in this brochure concerning the use of products described herein are based on tests believed to be reliable. However, it is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Eaton as to the effects of such use or the results to be obtained. Eaton assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government reculations.



